paco


F-4200



# SERVICE MANUAL

# COMPACT DISC DIGITAL AUDIO PLAYER





# WARNING

FOR CONTINUED SAFETY THE FOLLOWING PRECAUTIONS TO BE FOLLOWED DURING SERVICING

- 1. MAKE SURE POWER CORD IS DISCONNECTED BEFORE REPLACING ANY PARTS.
- 2. REPLACE WITH SAME TYPE, CRITICAL PARTS WITH AND MARK ON THIS DIAGRAM.
- 3. THE FOLLOWING TEST MUST BE IMPLEMENTED AFTER EACH REPAIR BEFORE RETURNING IT TO CUSTOMER.

  USE AN OHM-METER TO MEASURE THE D.C. RESISTANCE FROM BOTH A.C. CONDUCTORS TO ANY EXPOSED METALLIC PARTS SUCH AS A SCREW HEAD, METAL INLAYS FTC, THE RESISTANCE MEASURED TO BE 10 MEGAOHMS MINIMUM.

# CONTENTS

SPECIFICATION	<u>.</u> 1
DISASSEMBLY	2
EXPLODED VIEW-CABINET	5
EXPLODED VIEW-MECHANISM	6
EXPLODED VIEW PARTS LIST	7
ALIGNMENT AND ADJUSTMENT	8
DESCRIPTION OF INTERFACE	
TROUBLESHOOTING	14
SCHEMATIC DIAGRAM	18
P.C BOARD	20
BLOCK DIAGRAM	
WIRING DIAGRAM	23
ELECTRICAL PARTS LIST	24

# **SPECIFICATIONS**

### **AUDIO SPECIFICATIONS**

Signal/Noise Ratio ......95dB

### SIGNAL FORMAT

Sampling Frequency.......44.1 KHz

### **GENERAL SPECIFICATION**

### PERFORMANCE SPECIFICATIONS

Output Level		LIMIT 2.0V ±0.5V ±1dB
Frequency Response		
20Hz	± 0.5dB	± 1dB ± 1dB ± 2.5dB
Signal to Noise Ratio	95dB	90dB
Channel Separation		
1KHz	85dB	80dB
10KHz	80dB	70dB
Total Harmonic Distortion		
1KHz	0.01%	0.02%
10KHz	0.03%	0.1%
20KHz	0.8%	2.5%
Dynamic Range	90dB	80dB

### PICK UP


Type ..... Astigma 3 beam
Light Source .... Semiconductor laser

### • • • NOTE:


Nominal Specs represent the design specs; all units should be able to approximates these . . . some will exceed and some may drop slightly below these specs. Limit specs represent the absolute worst condition that still might be considered acceptable; in no case should a unit perform to less than within any limit spec.

### DISASSEMBLY


 To Remove the cover and the bottom cover (Figure 1) Remove 3 screws
 and 5 screws




To Remove the Front Panel (Figure 2)
 After taking off the cover and bottom cover, remove 7 screws 3




3. To Remove the TRAY Mechanism
Ass'y (Figure 3) After taking off the
front panel, rotate the pulley (A) right
and extract tray to A direction till
reach to tray stopper (b), and extract
the tray to A direction after pushing
the tray stopper.




4. To Remove the Mechanism (Figure 4)
After taking off the tray, remove 4
screws ④




5. To Remove the P.C.B (Figure 5)
A: After taking off the front panel, (refer to 2) remove 5 screws ⑤
B: After taking off the bottom cover (refer to 1), remove 5 screws ⑨
And To remove the Slider Volume, After remove 4 screws ⑥, remove the slider volume knob ⑦




 To Remove the Power Transformer (Figure 6)
 After taking off the Mechanism (refer to 4), remove 2 screws ⑦




- 7. To Remove the Head Phone Jack (Figure 5)
  After taking off the front panel (refer to 2), remove 2 screws ®
- 8. To Remove the Pick up (Figure 7)
  After taking off the Mechanism
  (refer to 4)
- A: To remove the guide shaft, remove the 4 screws ®
- B: To remove the rack, remove the 2 screws (9)



# **EXPLODED VIEW—CABINET**



# EXPLODED VIEW—MECHANISM



# **EXPLODED VIEW PARTS LIST**

### CABINET

### REF DESCRIPTION DRW NO. NO MECHA ASS'Y SETTING SCREW $\phi 3 \times 13$ , MECHA × 4 2 M1024 3 FRAME LF 1001 TRANS FORMER 4 POWER S/W 5 STOPPER-POWER CORD SF 1014 6 SCREW TAPPING WPH 3.5 × 10L TRANS FORMER × 2 PCB-FUSE SF 1020 8 POWER KNOB LF 1003 q S 4017 FOOT×4 10 12 BRACKET MECHA × 2 SF 1012 BOTTOM PLATE × 4 SF 1037 13 BACK PLATE SF 1036 14 SF 1019 PCB-MAIN 15 PCB-PANEL 16 LF 1013 17 EARTH PLATE M 1040 **BRACKET-PHONE JACK** LF 1016 18 HEAD PHONE JACK 19 **COVER BOTTOM** SF 1016 20 FRONT PANEL LF 1002 22 PCB-LAMP SF 1022 SCREW-MACHINE PHM3×6 23 POWER S/W×2 SCREW-TAPPING PH $\phi 3 \times 10$ 24 RCA JACK x 2 COVER-UPPER LF 1023 SCREW-TAPPING PH \$3 x 8 26 COVER-UPPER × 3 PCB-FUSE x 2 STOPPER-POWER CORD x 1 BRACKET MECHA × 2 PCB-PANEL × 4 PCB-MAIN × 5 BRACKET PHONE JACK × 2 COVER-BOTTOM $\times$ 5 BRACKET "B" $\times$ 2 FRONT PANEL x 7 LAMP TUBE SF 1026 27 FUSE 28 BRACKET "B" SF 1047 30 BRACKET "A" 31 SF 1046 32 **GROUND SPRING** SF 1045 SPACER-PCB SF 1041

### **MECHANISM PART LIST**

MECHANISM PART LIST								
REF NO	DESCRIPTION	DRW NO						
NO  1 2 3 3-1 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42	BELT "B" PULLEY 1st (TRACK SERVO) TURN TABLE SETTING BOLT SLIDER SCREW SLIDER FLAPPER DISC CLAMPER CLAMPING PLATE SCREW-TAP (BH) T3 × 7L SCREW-TAP (WPH) T3 × 8L WHEEL-2nd (TRAY SERVO) E-RING \$0.2.0 BELT "A" E-RING \$0.1.5 WHEEL-1st (TRAY SERVO) SPRING-FLAPPER PULLEY-MOTOR SCREW-BH M2 × 4.5L BASE ASS'Y MICRO SWITCH (AH 2502) SCREW-TAP (PH) T2.2 × 12L TRAY COVER-TRAY SCREW-PH M3 × 6 LEVER-CLUTCH ACTUATING RACK SCREW-TAP (BH) T2.2 × 6L MOTOR-SERVO (NBS6B-K) MOTOR-SPINDLE (NBS4R-K) LEAF SWITCH (MSW 1585) SCREW-PH M2.6 × 0.45 × 6L WHEEL-2nd GUIDE SHAFT PICK UP (KSS-152A) RACK (TRACK) SCREW-TAPPING PH \$0.2 × 6L WHEEL-3rd (TRACK SERVO) E-RING \$0.2.0 PROTECTOR DISC DISC LIFTER SPRING PLATE INSULATOR	M 1029 M 1029 M 1003 M 1013 AT 0204 M 1022 M 1011 M 1015 M 1014 M 1012  M 1008 M 1007 M 1032 M 1002 M 1001 SANKYO M1017 H 22004 M 1010 M 1009 SANKYO MIC ELEC M 1006 M 1030 SONY CD 4200 M 1004 M 1018 M 1016 M 1020 M 1021						

# **ALIGNMENT AND ADJUSTMENT**

When you happen to do either (1), or (2) be sure to perform the adjustments 1-6.

- Disassembly of the unit mechanism and replacement of parts.
- 2) Replacement of parts of the pick up assembly.
- ••PRESETTING


Adjustment	Circuit No.	Preset Position
RF GAIN	VR 101	Center
FE OFFSET	VR 103	Center
TE OFFSET	VR 102	Center
FE GAIN	VR 104	Center
TE GAIN	VR 105	Center
PLL	VR 201	Center

 Adjustment should be made in the following sequence.

### 1. RF GAIN Adjustment.

Don't perform this adjustment except when the parts of R102, R103, C102, C103, C104, PICK UP, IC 101, have been changed.


- 1) Instrument to be used
  - Oscilloscope
- 2) Adjusting procedure (Figure 1)
  - Connect the oscilloscope to TP5 (RF) and TP5 (GND)
  - •Load a disc in the player and set the player to play mode.
  - •Adjust VR101 so that oscilloscope indicate the figure shown in Figure 1.



### 2. FE OFFSET Adjustment.

Don't perform this adjustment except when the parts of VR103, IC101 PICK UP have changed.


- 1) Instrument to be used.
  - Oscilloscope
- 2) Adjusting Procedure (Figure 2)
  - Connect the Oscilloscope to TP3 (FE) and TP5 (GND).
  - Load a disc in the player, and set the player to STOP mode.
  - Adjust VR103 so that oscilloscope indicate the figure shown in Figure 2.



### 3. TE OFFSET Adjustment.

Don't perform this adjustment except when the parts of VR102, IC101, PICK UP.

- 1) Instrument to be used.
  - Oscilloscope
- 2) Adjusting Procedure.
  - Connect the oscilloscope to TP4 (TE) and TP5 (GND).
  - •Return to Counterclockwise VR105
  - Load a disc in the player, and set the player to play mode.
  - •Adjust VR102 so that oscilloscope indicate the figure shown in Figure 3.



•presetting to VR105, after adjusted.

### 4. FE GAIN Adjustment.


Don't perform this adjustment except when the parts of VR104, IC1, PICK UP have been changed.

- 1) Instrument to be used.
  - Oscilloscope
- 2) Adjusting Procedure
  - Connect the oscilloscope to TP3 (FE) and TP5 (GND).
  - Load a disc in the player, and set the player to play mode.
  - Adjust VR104 so that oscilloscope indicate the figure shown in Figure 4.

### 5. TE GAIN Adjustment.

Don't perform this adjustment except when the pats of VR105,IC101PICK UP have been change.


- 1) Instrument to be used.
  - Oscilloscope
- 2) Adjusting Procedure
  - Connect the oscilloscope to TP3 TP4 and TP5 (GND).
  - Load a disc in the player, and set the player to play mode.
  - Adjust VR105 so that oscilloscope indicate the figure shown in Figure 5.




### 6. Adjustment PLL.

Only perform this adjustment when IC201, IC401, VR201, C220, R218 are replaced.


- 1) Instrument to be used.
  - Oscilloscope
- 2) Adjusting Procedure
  - Connect the oscilloscope to TP6(GFS) and TP5 (GND)
  - •Load a disc in the player, and set the player to play mode.
  - •Adjust VR201 so that oscilloscope indicate the figure shown in Figure 6.






# DESCRIPTION OF INTERFACE


Signal	Timing and level	Contents
OPEN SW CLOSE SW SLED SW		TRAY OPEN TRAY CLOSE Inner SLED
FOK	Focus NG X OK	FOK sign
EFM	3T (T = 230nsec)	EFM comparator signal
ASY	3T (T = 230nsec)	EFM buffe sign
EFM PLCK PDO	Hi-lmp	EFM: EFM signal  PLCK: PLL clock about 4.3 MHz  PDO: PLL servo phase differentiation detction output








# **TROUBLE SHOOTING**

### (1) Does the TRAY Operated?











# **SCHEMATIC DIAGRAM 1**



# SCHEMATIC DIAGRAM 1



# • 14053B (IC560) INTEGRATED CIRCUITS INTEGRATED C

A 562 A 10 15 C 1815 C 1959


• 74LS74 (IC403)

# **SCHEMATIC DIAGRAM 2**


NOTE: RESISTANCE VALUES ARE INDICATED IN OHMS UNLESS OTHERWISE SPECIFIED (K = 1000 OHMS)

### SWITCH (KEY)

REFERENCE NO.	NAME	POSITION			
S901	POWER SW	OFF	S810	LAST	OFF
S801	INDEX	OFF	S811	FF	OFF
S802	REMAIN	OFF	S812	FR	OFF
\$803	CALL	OFF	S813	STOP	OFF
S804	PROGRAM	OFF	S814	OPEN/CLOSE	OFF
S805	REPEAT	OFF	S815	PLAY/PAUSE	OFF
S806	CLEAR	OFF	S816	SLED SW	ON
S807	NEXT	0FF	S817	OPEN SW	OFF
S808	5	OFF	S818	CLOSE SW	ON
S809	10	OFF			
S808	5	OFF			ON




# P.C BOARD



### P.C BOARD

PANEL PCB



• FUSE PCB


# P.C BOARD


OFF OFF OFF OFF OFF


OFF ON OFF ON


Fig. 1

SE











# **BLOCK DIAGRAM**



# **WIRING DIAGRAM**



# ELECTRICAL PARTS LIST

# MAIN PCB

REF NO	RESISTORS	%	CODE NO	REF NO	RESISTORS	%	CODE NO
R101	CARBON 1K 1/6W	5%	RI1001C7	R411	CARBON 150K 1/6W	5%	RI4701C4
R102	CARBON 22K 1/6W	5%	RI0220C5	R451	CARBON 220 1/6 W	5%	RI2200C4
R103	CARBON 33K 1/6W	5%	RI3302C1	R452	CARBON 220 1/6 W	5%	RI2200C4
R104	CARBON 100K 1/6W	5%	RI1003C3	R453	CARBON 33K 1/6 W	5%	RI3302C1
R105	CARBON 10K 1/6W	5%	RI1002C5	R454	CARBON 33K 1/6W	5%	RI3302C1
R106	CARBON 1K 1/6W	5%	RI1001C7	R455	CARBON 1K 1/6 W	5%	RI1001C7
R107	CARBON 4.7K 1/6W	5%	RI4701C4	R456	CARBON 1K 1/6 W	5%	RI1001C7
R108	CARBON 47K 1/6W	5%	RI4702C2	R457	CARBON 22K 1/6W	5%	Ri2202C0
R109	CARBON 10K 1/6W	5%	RI1002C5	R458	CARBON 22K 1/6W	5%	RI2202C0
R110	CARBON 10K 1/6W	5%	RI1002C5	R501	<b>CARBON 2.2K 1/6W</b>	5%	RI2201C2
R111	CARBON 220 1/6W	5%	RI2200C4	R502	CARBON 330K 1/6W	5%	RI3303C8
R112	CARBON 22K 1/6W	5%	RI2202C0	R503	CARBON 5.6K 1/6W	5%	RI5601C8
R113	CARBON 1K 1/6W	5%	RI1001C7	R504	CARBON 390 1/6W	5%	RI3900C5
R114	CARBON 10K 1/6W	5%	RI1002C5	R505	CARBON 6.8K 1/6W	5%	RI6801C3
R201	N.C	5%		R506	CARBON 3.3K 1/6W	5%	RI3301C3
R202	CARBON 100K 1/6W	5%	RI1003C3	R507	CARBON 6.8K 1/6W	5%	RI6801C3
R203	N.C	5%		R508	CARBON 10K 1/6 W	5%	RI1002C5
R204	CARBON 120K 1/6W	5%	RI1203C0	R509	CARBON 2.2K 1/6 W	5%	RI2201C2
R205	CARBON 82K 1/6W	5%	RI8202C6	R510	CARBON 5.6K 1/6 W	5%	RI5601C8
R206	CARBON 10K 1/6W	5%	RI1002C5	R511	CARBON 2.7K 1/6 W	5%	RI2701C8
R207	CARBON 56K 1/6W	5%	R25602C6	R512	CARBON 5.6K 1/6 W	5%	RI5601C8
R208	CARBON 180K 1/6W	5%	RI1803C0	R513	CARBON 8.2K 1/6 W	5%	RI8201C8
R209	CARBON 4.7K 1/6W	5%	RI4701C4	R514	CARBON 2.2K 1/6 W	5%	RI2201C2
R210	CARBON 560K 1/6W	5%	RI5603C4	R515	CARBON 5.6K 1/6 W	5%	RI5601C8
R211	CARBON 1M 1/6W	5%	RI1004C1	R516	CARBON 2.7K 1/6 W	5%	RI2701C8
R212	CARBON 22K 1/6W	5%	RI2202C0	R517	CARBON 5.6K 1/6 W	5%	RI5601C8
R213	CARBON 120K 1/6W	5%	RI1203C0	R518	CARBON 3.3K 1/6 W	5%	RI3301C3
R214	CARBON 3.3K 1/6W	5%	RI3301C3	R519	CARBON 100K 1/6W	5%	RI1003C3
R215	CARBON 3.3K 1/6W	5%	RI3301C3	R520	CARBON 1.2K 1/6 W	5%	RI1201C4
R216	CARBON 4.7K 1/6W	5%	RI4701C4	R521	CARBON 12K 1/6W	5%	RI1202C2
R217	CARBON 4.7K 1/6W	5%	RI4701C4	R522	CARBON 10K 1/6 W	5%	RI1002C5
R218	CARBON 100K 1/6W	5%	RI1003C3	R523	CARBON 4.7K 1/6 W	5%	RI4701C4
R219	CARBON 22K 1/6W	5%	RI2202C5	R524	CARBON 100K 1/6 W	5%	RI1003C3
C220	CARBON 10K 1/6 W	5%	RI1002C5	R525	CARBON 1.8K 1/6 W	5%	RI1801C4
C211	CARBON 10K 1/6W	5%	RI1002C5	R526	CARBON 820K 1/6 W	5%	RI8203C4
R301	CARBON 22K 1/6W	5%	R12202C0	R551	CARBON 3.3K 1/6 W	5%	RI3301C3
R302	CARBON 22K 1/6W	5%	RI2202C0	R552	CARBON 12K 1/6 W	5%	RI1202C2
R303	CARBON 22K 1/6 W	5%	RI2202C0	R553	CARBON 10K 1/6 W	5%	RI1002C5
R304	CARBON 2.2K 1/6 W	5%	RI2201C2	R554	CARBON 22K 1/6 W	5%	RI2202C0
R305	CARBON 2.2K 1/6 W	5%	RI2201C2	R555	CARBON 1K 1/6W	5%	RI1001C7
R401	CARBON 150K 1/6W	5%	RI1502C0	R556	CARBON 100K 1/6 W	5%	RI1003C3
R402	CARBON 150K 1/6W	5%	RI1503C0	R557	CARBON 100K 1/6 W	5%	RI1003C3
R403	CARBON 82K 1/6 W	5%	RI8202C6	R558	CARBON 4.7K 1/6 W	5%	RI4701C4
R404	CARBON 82K 1/6 W	5%	RI8202C6	R559	CARBON 4.7K 1/6 W	5%	RI4701C4
R405	CARBON 10K 1/6 W	5%	RI1002C5	R560	CARBON 1.5K 1/6W	5%	RI1501C4
	CARBON 10K 1/6 W	5%	RI1002C5	R561	CARBON 10 1/6W	5%	RI0100C5
	CARBON 10K 1/6W	5%	RH1002C5	R562	CARBON 10 1/6 W	5%	RI0100C5
R408	CARBON 10K 1/6 W	5%	RI1002C5	R601	CARBON 2.2K 1/6 W	5%	RI2201C2
	CARBON 10K 1/6 W	5%	RI1002C5	R602	CARBON 330K 1/6 W	5%	RI3303C8
	CARBON 10K 1/6 W	5%	RI1002C5	R603	CARBON 5.6K 1/6 W	5%	RI5601C8

REF NO	RESISTORs	%	CODE NO	REF NO	RESISTORS	%	CODE NO
R604	CARBON 390 1/6 W	5%	RI3900C5	C205	ELECTROLYTIC 2.2μ 50V		PA2250K1
R605	CARBON 6.8K 1/6 W	5%	RI6801C3	C206	POLYESTER 0.015μ 50V	5%	PM1535G1
R606	CARBON 3.3K 1/6 W	5%	RI3301C3	C207	N.C		
R607	CARBON 6.8K 1/6 W	5%	RI6801C3	C208	POLYESTER 0.1 µ 50V	5%	PM1045G0
R608	CARBON 10K 1/6W	5%	RI1002C5	C209	POLYESTER 0.047μ 50V	5%	PM4735G1
R609	CARBON 2.2K 1/6W	5%	RI2201C2	C210	POLYESTER 0.1μ 50V	5%	PM1045G0
R610	<b>CARBON 5.6K 1/6 W</b>	5%	RI5601C8	C211	ELECTROLYTIC 3.3μ 50V		PA3350G0
R611	CARBON 2.7K 1/6 W	5%	RI2701C8	C212	ELECTROLYTIC 3.3µ 16V		PA3360C7
R612	CARBON 5.6K 1/6 W	5%	RI8201C8	C213	POLYESTER 0.01μ 50V	5%	PM1035G4
R613	CARBON 8.2K 1/6 W	5%	RI8201C8	C214	ELECTROLYTIC 33μ 16V		PA3360C7
R614	CARBON 2.2K 1/6 W	5%	RI2201C2	C215	ELECTROLYTIC 33μ 16V		PA3360C7
R615	CARBON 5.6K 1/6 W	5%	RI5601C8	C216	ELECTROLYTIC 33μ 16V		PA3360C7
R616	CARBON 2.7K 1/6 W	5%	RI2701C8	C217	POLYESTER 0.033μ 50V	5%	PM3335G0
R617	CARBON 5.6K 1/6 W	5%	RI5601C8	C218	ELECTROLYTIC 0.47μ 50V		PA4740G1
R618	CARBON 3.3K 1/6 W	5%	RI3301C3	C219	ELECTROLYTIC 0.3μ 16V		PA3360C7
R619	CARBON 100K 1/6 W	5%	RI1003C3	C220	POLYESTER 0.01µ 50V	5%	PM1035G4
R620	CARBON 1.2K 1/6 W	5%	RI1201C4	C221	POLYESTER 6800p 50V	5%	PM6825G4
R621	CARBON 12K 1/6 W	5%	RI1202C2	C222	ELECTROLYTIC 10μ 50V		PA1060C2
R622	CARBON 10K 1/6W	5%	RI1002C5	C223	ELECTROLYTIC 1μ 50V		PA1050G0
R623	CARBON 4.7K 1/6 W	5%	RI4701C4	C301	CERAMIC 39p 50V		QP3902J2
R624	CARBON 100K 1/6 W	5%	Ri1003C3	C302	CERAMIC 39p 50V		QP3902J2
R625	CARBON 1.8K 1/6 W	5%	RI1801C4	C303	CERAMIC 100p 50V		QP1021J7
R626	CARBON 820K 1/6 W	5%	RI8203C4	C304	ELECTROLYTIC 33μ 16V		PA3360C7
R651	CARBON 10K 1/6 W	5%	RI002C5	C305	ELECTROLYTIC 33μ 16V		PA3350C7
R652	CARBON 10K 1/6 W	5%	RI002C5	C306	ELECTROLYTIC 33µ 16V		PA3360C7
R653	CARBON 10K 1/6 W	5%	RI002C5	C307	ELECTROLYTIC 33µ 16V		PA3360C7
R654	CARBON 10K 1/6 W	5%	RI002C5	C308	ELECTROLYTIC 33µ 16V	1	PA3360C7
R655	CARBON 4.7K 1/6 W	5%	RI4701C4	C309	ELECTROLYTIC 33µ 16V		PA3360C7
R656	CARBON 4.7K 1/6 W	5%	RI4701C4	C401	CERAMIC 1000p 50V		QP1021J7
R901	CARBON 470 1/6 W	5%	RI4700C6	C402	CERAMIC 1000p 50V		QP1021J7
R902	CARBON 470 1/6 W	5%	RI4700C6	C403	ELECTROLYTIC 2.2µ 50V		PA2250K1
R903	CARBON 470 1/6 W	5%	RI4700C6	C404	ELECTROLYTIC 33µ 16V		PA3350C7
R904	CARBON 470 1/6 W	5%	RI4700C6	C405	CERAMIC 220p 50V	1	QP2211J6
				C452	CERAMIC 220p 50V		QP2211J6
	CAPACITORS			C501	POLYESTER 560p 50V		PS5614G0
т				C502	POLYESTER 1500p 50V	5%	PM1525G5
C101	ELECTROLYTIC 33μ 16V		PA3360C7	C504	POLYESTER 1500p 50V	5%	PM1525G5
C102	CERAMIC 1000p 50V		QP1021J7	C505	POLYESTER 1500p 50V	5%	PM1525G5
C103	ELECTROLYTIC 100μ 10V		PA1077B8	C505	POLYESTER 1500p 50V	5%	PM1525G5
C104	POLYESTER 0.01µ 50V	5%	PM1035G4	C506	POLYESTER 1500p 50V	5%	PM1525G5
C105	POLYESTER 0.01μ 50V	5%	PM1035G4	C507	POLYESTER 1500p 50V	5%	PM1525G5
C106	POLYESTER 0.01μ 50V	5%	PM1035G4	C508	POLYESTER 1500p 50V	5%	PM1525G5
C107	POLYESTER 0.01µ 50V	5%	PM1035G4	C509	POLYESTER 1500p 50V	5%	PM1525G5
C108	ELECTROLYTIC 0.47μ 50V		PA4740G1	C510	POLYESTER 1500p 50V	5%	PM1525G5
C109	POLYESTER 0.01µ 50V	5%	PM1035G4	C510	POLYESTER 1500p 50V	5%	PM1525G5
C110	ELECTROLYTIC 33μ 16V		PA3360C7	C512	POLYESTER 4700p 50V	5%	PM4725G5
C111	POLYESTER 0.033µ 50V	5%	PM3335G0	C512	POLYESTER 4700p 50V	5%	PM4725G5
C112	CERAMIC 2200p 50V		QP2221J2	C514	POLYESTER 390p 50V	5%	PS3914G4
C113	POLYESTER 4700p 50V	5%	PM4725G5	C515	POLYESTER 390p 50V	5%	PS3914G4
C114	POLYESTER 33 <sub>µ</sub> 16V 50V	5%	PA3360C7	C516	POLYESTER 10µ 110V	5%	PA1069C2
C201	N.C			C551	ELECTROLYTIC 4.7µ 50V	370	PA4750C3
C202	N.C			C552	ELECTROLYTIC 47µ 16V		PA4760C8
C203	CERAMIC 10p 50V		QP1001J6	C553	ELECTROLYTIC 470µ 16V		PA4777C8
C204	ELECTROLYTIC 22μ 16V		PA2260C6	C561	ELECTROLYTIC 33µ 16V	[	PA3360C7
							, 7,000007

C562 ELECTROLYTIC 33μ 16V PA3360C7 Q651 KTC 1815 C601 POLYESTER 560p 50V 5% PS5614G0 Q652 KTA 1015 C602 POLYESTER 1500p 50V 5% PM1525G5 Q653 KTC 1815	TC1815Y7
C601 POLYESTER 560p 50V 5% PS5614G0 Q652 KTA 1015	
	TA1015Y0
C602   POLYESTER 1500p 50V   5%   PM1525G5   Q653   KTC 1815	TC1815Y7
C603   POLYESTER 1500p 50V   5%   PM1505G5   Q654   KTC 1815	TC1815Y7
C604   POLYESTER 1500p 50V   5%   PM1505G5   Q901   KTC 1959	TC1959Y4
C605   POLYESTER 1500p 50V   5%   PM1505G5   Q902   KTA 562	TA0562Y3
C606   POLYESTER 1500p 50V   5%   PM1505G5	
C607   POLYESTER 1500p 50V   5%   PM1505G5     REF NO   ICs	CODE NO
C608   POLYESTER 1500p 50V   5%   PM1505G5	
C609   POLYESTER 1500p 50V   5%   PM1505G5   IC101   CXA-1081M	UD0070S6
C610   POLYESTER 1500p 50V   5%   PM1505G5   IC201   CXA-1082 AQ	UD0090S7
C611   POLYESTER 1500p 50V   5%   PM1505G5   IC301   CXD-1135Q	UD0080S2
C612 POLYESTER 4700p 50V 5% PM4725G5 IC302 CXK-5816 PN-15V	UB0010S2
C613 POLYESTER 4700p 50V 5% PM4725G5 IC303 PCM-54HP	UD0040B3
C614 POLYESTER 390p 50V 5% PS3914G4 IC401 LC-6510-3066	UA0041S1
C615 POLYESTER 390p 50V 5% PS3914G4 IC402 HD-14015 BP	UL0060M8
C616 ELECTROLYTIC 10µ 16V PA1069C2 IC403 HD-74LS74AP	LC0030H2
C651 ELECTROLYTIC 0.22μ 50V PA2249G8 IC404 IR 94558	UO0010S4
C901 ELECTROLYTIC 220μ 16V PA2287C2 IC451 IR3F02	UO0030S5
C902   ELECTROLYTIC 220μ 16V   PS2287C2   IC501   IR3F02   C903   FLECTROLYTIC 470μ 16V   PA4777B5   IC502   IR3F02	UO0030S5 UO0030S5
	UC0050H3
	UD0020S0
Social Electrication for the first section of the f	UO0030S5
10000   10000   10000	UO0030S5
C907   ELECTROLYTIC 100μ 25V   PA1077D5   IC602   IR3F02   C909   ELECTROLYTIC 33μ 16V   PA3360C7   IC901   GL 7805	UU0010G7
C910 ELECTROLYTIC $33\mu$ 16V PA3360C7 IC902 GL 7905	UU0020G3
C911 ELECTROLYTIC 220μ 16V PA2277C6	
C912 ELECTROLYTIC 220μ 16V PA2277C6 REF NO DIODEs	CODE NO
	1/000401/0
D401   IN4148     D402     D402       D402	KS0012K2 KS0012K2
D402 IN4148	KS0012K2
Q101 KTA 1015 TA1015Y0 D551 IN4148	KS0012K2
Q102   KTC 1815   TC1815Y7   D901   IN4002	KR0042K3
Q103   KTC 1815   TC1815Y7   D902   IN4002	KR0042K3
Q201 KTA 562 TA0562Y3 D903 IN4002	KR0042K3
Q202   KTC 1959   TC1959Y4   D904   IN4002	KR0042K3
Q203   KTA 562   TA0562Y3   D905   IN4002	KR0042K3
Q204   KTC 1959   TC1959Y4   D906   IN4002	KR0042K3
Q205   KTA 562   TA0562Y3   D907   IN4002	KR0042K3
Q206   KTC 1959     TC1959Y4   D908   IN4002	KR0042K3
Q207   KTA 562   TA0562Y3   D909   IN4148	KS0042K2
Q208   KTC 1959   TC1959Y4	
Q209 KTC 1815 TC1815Y7 REF NO VARIABLE RESIS	TORs CODE NO
Q210 KTC 1815 TC1815Y7	
Q401 KTA 965 TA0965Y0 VR101 2KB	VH0400U3
Q402 KTC 2235 TC2235Y6 VR102 20KB	VH0430U0
Q403 KTC 1815 TC1815Y7 VR103 50KB	VH0500U6
Q404 KTC 1815 TC1815Y7 VR104 20KB	VH0430U0
Q551   KTC 1815     TC1815Y7   VR105   20KB	VH0430U0
	VH0400U3
Q552 KTA 1015 TA1015Y0 VR201 2KB	111040003
Q552   KTA 1015   TA1015Y0   VR201   2KB   TA1015Y0   CR201   2KB   CR201	7710-10003
Q552 KTA 1015 TA1015Y0 VR201 2KB	71040003

REF NO	INDUCTORS		CODE NO	REF NO	RESISTORs	%	CODE NO
L401	LAL04KB 100K		OC0017D2	R803	CARBON 82 1/4W	5%	RE0820E5
L402	LAL 04KB 100K	ļ	OC0017D2	R804	CARBON 82 1/4W	5%	RE0820E5
L403	LAL 04KB 100K		OC0017D2	R805	CARBON 82 1/4W	5%	RE0820E5
				R806	CARBON 82 1/4W	5%	RE0820E5
HS901	HEAT SINK		EG0120N8	R807	CARBON 82 1/4W	5%	RE0820E5
HS902	HEAT SINK		EG0120N8	R809	CARBON 4.7K 1/4W	5%	RE4701E8
113902	HEAT SINK		EGU 120NO	R810	CARBON 4.7K 1/4W	5%	RE4701E8
CD404	134/1 0040 00		A 114 4 0 0 0 1 1 0	R811	CARBON 4.7K 1/4W	5%	RE4701E8
CP101	LWL-0640-08		NW1320H2	R808	CARBON 3.3K 1/4W	5%	RE3301E7
CP102	LAL-0640-08		NW 1815H0				
CP103	LWL-0640-06		NW1310M6	REF NO	ICs		CODE NO
CP104	LWL-0640-05		NW1300H1				
CP105	LWL-0640 04		NW1290H7	IC210	LB1216 (LED DRIVER)		UL0020S3
CP106	LWL-0640-04		NW1290H7	IC211	SN74NS145N (TTL IC)		UL0045M7
CP107	LWL-0640-02		NW1270H6		•		
CP108	LWL-0640-02		NW1330H7	REF NO	DIODES		CODE NO
CP109	LWL-0640-03		NW1280H2	- 10	Biode		OODE NO
CP110	LWL-0640-03		NW1280H2	D801	IN4148		KS0012K2
CP111	LWL-0640-02		NW1270H6		IN4148		KS0012K2
CP112	LWL-0640-03		NW1280H2	D802	IN4148		
CP113	LWL-0640-03		NW1280H6	D803			KS0012K2
				D804	IN4148		KS0012K2
	FUOE DOD			D805	IN4148		KS0012K2
REF NO	FUSE PCB		CODE NO	D806	IN4148		KS0012K2
				D807	IN4148		KS0012K2
C801	CERAMIC CAPACITOR 0.01 $\mu$ (LINE CAPACITOR)		QM 4720 MO	D808	IN4148		KS0012K2
	HOLDER FUSE			REF NO	MISCELLANEOUS		CODE NO
	FUSE (0.2A NM TYPE)	2EA	1 1				
	TAP STUD			FL301	LED DISPLAY (2 digit)		KL0004S0
				FL302	LED DISPLAY (4 digit)		KL0103S5
REF NO	PANEL PCB		CODE NO	D901	LED SL-106		KL0005S7
NEI NO	PANEL FOD		0002.110	D902	LED SL-106		KL0005S7
				D903	LED SL-106		KL0005S7
R801	CARBON 82 1/4W	5%	RE0820E5	D904	LED SL-106		KL0005S7
R802	CARBON 82 1/4W	5%	RE0820E5	D905	LED SL-106		KL0005S7
				D906	LED SL-206		KL0003S5
			l i	D907	LED SL-202		KS0012K2
			1	D908	LED SL-106		KS0005S7
			<b>!</b>	REF NO	VR PCB		CODE NO
			!!	1121 110			
			1		VJ4512G PRN		VS0070K6
! !	l l		}		12.5G 3 15A 20K×2		1
			1	CP112	SHIELD WIRE ASS'Y 3P		
			1	CP113	SHIELD WIRE ASS'Y 3P		
1	,		1				
			1				
1 1			J ì				
]			1				
				]			.
·							
			[ 1				
	1.		1				
			] [				

M	F	M	0	
	_			

**CAUTION;** Parts are subject to change for improvement.